



ROCKFLEET

IMPORTANT: Your RockFLEET is supplied with a 3 metre cable to allow the cable to be connected to the power supply below decks without cutting the cable. Connection to the Power Supply should only be made below decks where it is not exposed to the elements. If it is necessary to cut and join the cable above decks you must ensure the cable join uses a suitable waterproof connector, marine adhesive heatshrink, or waterproof cable boot and is completely sealed against water and salt ingress. Installation should be completed by a suitably qualified technician. Unit damage caused by improper installation may result in your warranty being void. **For further installation information please contact us on 1300 882 448 or mail@pivotel.com.au**

Flat Steel Mount Installation and Information Guide

Optional with your ROCKFLEET



1x RockFLEET



1x Flat Steel Mount
(deck mount)



4x White Plastic
Washers



4x Stainless Machine
Screws (M5 8mm)



DECK of Vessel



Fitting Instructions

- 1 Fit your ROCKFLEET to the flat steel (deck) mount using the stainless machine screws & washers provided within the box
- 2 Make sure the white plastic washers go between the ROCKFLEET and the flat steel (deck) mount!
- 3 Run the power cable attached to the ROCKFLEET to your vessels power supply. Make sure you check the length before installation
- 4 Secure the flat steel (deck) mount to your vessels deck (no screws provided)

Maximum screw torque limit - 6 N.m

Maximum Bend Radius



6 x outer diameter

Temperature Range



-40°C to +80°C

Red & Black Cable Cores



Red Core = +ve

Black Core = -ve

Power Supply Required



Attach the cable to a fused (2A) 8-32v DC supply