

IMPORTANT: Your RockFLEET is supplied with a 3 metre cable to allow the cable to be connected to the power supply below decks without cutting the cable. Connection to the Power Supply should only be made below decks where it is not exposed to the elements. If it is necessary to cut and join the cable above decks you must ensure the cable join uses a suitable waterproof connector, marine adhesive heatshrink, or waterproof cable boot and is completely sealed against water and salt ingress. Installation should be completed by a suitably qualified technician. Unit damage caused by improper installation may result in your warranty being void. **For further installation information please contact us on 1300 882 448 or mail@pivotel.com.au**

Rokk Mount Installation and Information Guide

Optional with your ROCKFLEET



1x Rokk Mount



4x White
Plastic Washers
(1.5mm)



4x Small
Metal Washers



4x Stainless
Machine Screws
(M5 10mm)



4x Stainless
Machine Screws



Fitting instructions

- 1 Fit your ROCKFLEET to the Rokk mount by attaching it to the top half first by using the stainless machine screws provided within the box;
- 2 Place a small metal washer between the M5 10 machine screw and the top half of the Rokk mount;
- 3 Then, place a white plastic washer between the top half of the Rokk mount and the ROCKFLEET unit!
- 4 With the ROCKFLEET fitted to the top half of the Rokk mount, place it onto a rail / pole / bar;
- 5 Then, lining up the bottom plate underneath the rail / pole / bar;
- 6 Secure the bottom half of the Rokk mount to the top half using the provided machine screws
- 7 Make sure all machine screws are tightened at the correct torque and the ROCKFLEET does not move!



Maximum screw torque limit - 6 N.m

Maximum Bend Radius = 6 x outer diameter

Red & Black Cable Cores



Red Core = +ve

Black Core = -ve

Power Supply Required



Attach the cable to a fused (2A) 8-32v DC supply